AC18Pro IP Camera Manual


[Part 1: Connect and manage cameras using mobile APP]

Please go google play or Apple store download mobile APP, the name is AC18Pro and install it into your mobile phone The first time you run the APP, you need to register an account. You can use your email or mobile phone number to register an account, and then use the registered account to log in to the APP.


[1], Configure the camera using WIFI

1. If your camera has WIFI function. Before connecting the power adapter of the camera, please make sure that the LAN port of the camera is not connected to the Ethernet cable (if you have connected it, please disconnect it and press the reset button for 5 seconds to restore the camera to factory settings). After connecting the power, wait 10 seconds.

2. Before using the mobile APP to configure the camera, please connect your mobile phone to your WIFI router via WIFI. 3. Open the APP and click the Add button to add a camera (as shown in Figure 1). And select WIFI (as shown in Figure 2), the software will automatically obtain the WIFI of the mobile phone, and please enter the WIFI password (the WIFI connection password of the wireless router). Click Next (as shown in Figure 3)




After entering the interface of Figure 4, wait for a few seconds, the APP will automatically enter the interface of Figure 5, and the camera will start to match the code through sound waves. When you hear a "di" on the phone, it means that the camera is successfully connected to your wireless router via WIFI (as shown in Figure 6). If your camera does not have a microphone and a speaker at the same time, the sound wave code matching cannot be completed, but you can also add the camera after aligning the QR code on the phone screen with the camera lens. Click the camera on Figure 7, and you will enter the camera's monitoring and management interface (as shown in Figure 8). The camera has been added successfully.




[2], Add a camera by scanning a QR code

If your camera does not have WIFI function, please connect the ethernet cable to your switch/router and connect the power adapter. Select "Wired connection camera", as shown in Figure 9, enter the interface of scanning the QR code to add a camera, point the mobile phone at the QR code on the camera body to scan (as shown in Figure 10), after scanning is successful, please provide your Customize a name for the camera, and click "BIND IT" to complete the addition (as shown in Figure 12)



[3], Add cameras via LAN connection

If the QR code cannot be found on the camera, you can click "Click here to add a device" to add the camera through the LAN search (as shown in Figure 12), enter the search page, and the APP will automatically search for the camera, as shown in Figure 13 display, and then click the camera to complete the addition.



Part 2: Add and manage cameras using PC software

[1],Install search tool on your PC

1, Run" AjDevTools_V5.1.9_20201215.exe" and complete the installation



× 请选择你要安装的语言

2

×

2, Run the software, as shown below

₫ AJ DEVICE TOOLS FOR SEARCHING/CONFIGURING/UPGRADDING V5.1.9_20201215

P Address	HTTP	Model	Title Name	Firmware	Version		Status		All subn	SN.
192.168.1.59	80	MC800S	Camera	MC800S_A	V2_STARC-RTMP-H5 V	3.0.6.4 build	00:32:15 Alarm:video	Human shape detected.	close	EF0000
Batch Reset	Batch R	eboot IP Ba	tch Setting Bat and	ch Set video audio encode	All subnet ONVIF	Batch Timing Maintenance	Video window	print label		
Jpgrade irmware	::\安佳\新界面-	台湾\MC500L-L8\	firmware_MC500L8_1	/0_AF Browse	Batch Sync Time	Batch Set Password	Batch Set Language	Batch Set Platform		Copy QR
pgrade mware by path	:\Users\Public	\Documents		Browse	50HZ/60HZ	Batch Snap Picture	Control IO Output	Audio	261	Code
Upload				Browse	Batch Download	Batch Set Title	Batch Motion	Factory Mode	a2346	Print QR Code

3, Here you can modify the IP address of the camera, upgrade the firmware and other parameter settings. Right-click on the IP address to open the camera with a browser, as shown in the figure below.

) A11	NetCard All H	letCards	~	Start Search	Export to Es	ccel 🔽 QE code 🗌	Audio 🛛 Full scree	in switching stree	Total	1 Seleted
CP Address	HTTP	. Model	Title Name	Firmware Versi			Status		All subn	SM.
192.168.1	. 59 80	MC800S	Goto Web		TARC-RTMP-H5 V	3.0.6.4 build	00:35:18 Alarm:video	Human shape detected.	close	EFOO
			Remote config	>						
			Video window	>						
			One-click play							
			Only Play Audio							
			Stop playing							
			Reboot IPC							
			Modify IP address							
			Alloc available IP add	resses						
			Factory setting							
			Snap picture							
			Open snap directory							
			P2P ID UPLOAD	>						
			ISP BIN upload	>						
			ONVIF	>						
			нік	>						
			DH	>						
			TST	>						
Batch Rese	et Batch	Reboot	IMPORT XML EXPORT XML		subnet ONVIF	Batch Timing Maintenance	Video window	print label		
Upgrade Firnware	E:\安佳\新界面	i-台湾\MC500	COPY XML BATCH ADD		h Sync Time	Batch Set Password	Batch Set Language	Batch Set Platform		Copy QF
Upgrade rmware by path	C:\Users\Publ	ic\Document:	Default User Setting		OHZ/60HZ	Batch Snap Picture	Control IO Output	Audio	2003	Code
Upload config			Copy SN CopyUUID		ch Download Config	Batch Set Title	Batch Motion Detection	Factory Mode	12940	Print QF Code

4,Enter the browser login interface, login user name: admin, password: 123456, as shown in the following figure (if the browser prompts you to download and install the plug-in, please download and install it):




5, Then click login



[2],Use PC software to search and add cameras

- 1, Install the LMS computer software.
- 36X 4K IPC




安装语言		×
2	请选择你要安装的语言	
	English	~
	OK	Cancel

The software supports English, Simplified Chinese and Traditional Chinese (if you want to support other languages, we can provide you with language packs, you can translate into the language you want, and then we can provide you with software customization)


- 2, Follow the prompts to complete the software installation
- 3, Run the LMS software:user:admin,password:123456



Click LOGIN to log in to the software



4. Search and add cameras.



Click "Devices>""Start Search">click"3">add >successfully added





Double click on the IP address and the video will automatically appear in the video box on the right.

[3], Preview and control cameras with AC18PRO PC software

1, Double-click the AC18PRO software in the directory, follow the prompts to complete the installation of the camera, and then run the camera.

늘 Manual
AC18Pro_install_V1.0.0_20220408.exe
AjDevTools_V5.1.9_20201215.exe
LMS_install_V5.0.5_20211123.exe

2, run and login AC18PRO,

The username and password here are the account you registered for the first time on your mobile phone.

Click login button go to AC18PRO

You will see all the cameras under your account, you can preview the

cameras and view the video playback in this way



